

Fitting instructions for corsa / astra / cavalier gear lever.

1. Remove gaiter by pressing towards rear of car at points arrowed. Lift up front of gaiter, and then push the rear of the gaiter forwards to release it.



2. Select first gear, then lift gaiter up over the gear knob. The securing clip is arrowed below.



3. Use a flat blade screwdriver to lever the clip to the left.



The clip is unfastened:



4. Use your screwdriver to ease the clip out. Do this stage slowly, until you can lift out the gear lever. (It can be tricky to re-insert the clip if you remove it fully and have large hands). Take care not to get any of the grease from the base of the lever on your car / clothes.



Lift out the gear lever .



5. Put the bottom half of the lever into a bag to protect yourself from the grease. Turn the lever upside down as shown in the picture below.

Remove the tiwrap (located where the red arrow is, a replacement tiwrap is included). You will then be able to carefully remove the gaiter from your original lever.

Transfer the gaiter to the new pool ball lever. Note that you must reassemble it the correct way round. The wide end of the gaiter is to the front when the plastic block (blue arrow) is to the left.

Insert the tiwrap and tighten it, making sure it locates in the groove in the lever.



6. Insert the new lever, making sure the reverse stop is at the left hand side as shown.



7. Push the clip back thru the gear lever, and use your screwdriver to securely clip it onto the lever.



Clip reinstalled correctly. A spare clip is included with your gear lever in case yours gets damaged. If not required you can dispose of it.



8. Insert the tabs on the rear of the gaiter into the back of the console. Then press down at the front of the gaiter to secure it.



9. If required, you can straighten the ball by carefully turning it. Check that you can select all gears before driving your car. Enjoy your new pool ball gear knob!

