

## Chrysler PT Crusier pool ball gear knob fitting guide.

© [www.mr8ball.com](http://www.mr8ball.com)

### Step 1: Remove original gear knob.

Pull the knob sharply upwards to remove. Some early models may also be glued, so if you are unable to remove it heat gently with a hairdryer to soften the glue and then pull upwards.



### Step 2: Fit aluminium adaptor.

Put the adaptor onto the lever as shown below and tighten the securing grub screws with an allen key.



### Step 3: Fit ball to adaptor.

The ball then screws onto the adaptor until the base is flush / covering the adaptor.



**Please ensure ball is firmly fixed into place before driving your vehicle.**

